
### CTSIZ005



# Steering Wheel Control Interface

for Isuzu Vehicles



i. Interface Box ii. ISO Connector (16-pin) iii. Vehicle Specific Connector iv. Additional Flying Wires v. Vehicle Specific Antenna Connector vi. FM/AM & DAB Radio Connectors vii. Bare Connections for Vehicle viii. Tap Splice Connectors ix. Stereo Connection (Patch) Lead Elements



### APPLICATION \_\_\_\_

Note: Application data is subject to change at any time

Isuzu D-Max

2020 - UP

For vehicles without an OEM touch screen.

### FEATURES \_\_\_\_\_

- Retains Factory Steering Wheel Control Functions
- Retains Factory Phone Buttons
- Provides Outputs for Speed Pulse, Park Brake & Reverse Gear
- Includes Antenna Adapter Connections for FM/AM & DAB Retention

#### **DISCLAIMER**

The information provided in this document is subject to change without notice due to manufacturer changes and/or improvements to the product/s. This instruction manual is based on documented data and research. The manufacturer of this product cannot be held responsible for any changes made to the vehicle by the manufacturer or damages that may occur through the installation of this product in accordance with the steps outlined herein.

### PRODUCT INFORMATION

#### CTSIZ005

Steering wheel control interface for the Isuzu D-Max. This interface retains the steering wheel controls and factory phone buttons (if vehicle is equipped).

Please note: this product is for vehicles with non-touch screens as standard.

### WIRING KEY

#### IN WIRING HARNESS

**Purple** Right Rear Speaker + Yellow Permanent 12V Purple/Black Right Rear Speaker -Black Ground Left Rear Speaker + Green Ignition 12V Red Left Rear Speaker -Green/Black Illumination Orange Right Front Speaker +

Grey Right Front Speaker +
Grey/Black Right Front Speaker White Left Front Speaker +
White/Black Left Front Speaker -

#### ADDITIONAL CONNECTIONS

Pink Speed Pulse Green Park Brake Purple Reverse Gear

### PRIOR TO INSTALLATION

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure that the correct tools are used during the installation to avoid damage to the vehicle or product.

Connects2 can not be held responsible for the installation of this product.

### **INSTALLATION GUIDE**

See wiring diagram on Pg.4 for more information

Before installing the interface, the factory stereo must be removed and disconnected. To do this, please consult the vehicle owner's manual/handbook or contact a fitting professional.

1. Connect the 16 Pin connector from the stereo connection (patch) lead to the interface box & connect the opposite end to the steering wheel control input on the back of the aftermarket stereo

NOTE: This may be a 3.5mm jack connector or a wired input depending on the brand of aftermarket stereo being fitted. Please consult the table below along with the imagery on Pg.4.

- IMPORTANT: THIS STEP MUST BE COMPLETED BEFORE CONNECTING POWER TO THE INTERFACE. FAILURE TO DO SO MAY RESULT IN A LACK OF FUNCTIONALITY AND THE NEED TO RE-INSTALL THE PRODUCT.
- 2. Connect the 14 Pin connector from supplied wiring loom to the interface box
- 3. Undo the screw that holds the drivers side foot panel in place and remove it fully to expose the wring located here. Once done, use one of the splice connectors to tap the Reverse Gear wire into the highlighted Red wire found here (see Fig. 1 overleaf).
- 4. Undo the screw that holds the passenger side foot panel in place and remove it fully to expose the wring located here. Once done, use one of the splice connectors to tap the Speed Pulse wire into the highlighted Purple wires found here (see Fig.2 overleaf).
- 5. Connect the power/speaker ISO connector to the power/speaker ISO connector at the rear of the aftermarket stereo.

NOTE: For aftermarket stereos which <u>do not</u> have an ISO connector, please see "Wiring Key" above for information on which wires to connect. Some interfaces may also have additional 'flying' wires which can be connected to the vehicle to support various features i.e. parking brake trigger, reverse gear and speed pulse. Details of these can be found under 'Additional Connections'.

2

CTSIZ005\_IG\_v2

6. Connect the 16 pin vehicle specific connector to the vehicles main power connector & proceed to test the stereo and steering wheel control functionality for correct operation before reassembling the vehicle dashboard. If steering wheel control functions are unresponsive, please uninstall the interface and wiring and re-install carefully in accordance with the above steps.

For further help, please contact and fill out a support ticket with the full details of your issue at: support.connects2.com/tickets/technical






## STEREO CONNECTION (PATCH) LEAD

To benefit from steering wheel controls, utilise the supplied stereo connection (patch) lead. This will need to be wired up correctly for the desired aftermarket stereo installed. See below a list of applicable units:

J1	J2	J3	J4	J5	Brand	Connections
0	1	0	0	0	Alpine	3.5mm Jack
1	1	0	0	0	Blaupunkt	3.5mm Jack
0	0	1	0	0	Clarion	3.5mm Jack
0	1	1	0	0	JVC	Key 1
0	0	0	1	1	Kenwood	Key 1 & Key 2
1	0	0	0	0	Pioneer	3.5mm Jack
0	1	0	1	0	Sony	3.5mm Jack
0	0	0	0	1	Zenec	Key 1

#### Configuration Assignments (1=Link Made, 0=Cut Link)




Need help? Visit support.connects2.com/tickets/technical

## STEREO CONNECTION (PATCH) LEAD



### STEERING WHEEL CONTROL FUNCTIONALITY

The following diagram, though based on careful research, is an example only. Individual steering wheel control configurations may differ.



- 1. Volume Up
- Volume Down
- Track Forward
- 4. Track Back
- 5. Source (**Short Press**) Mute (**Long Press**)
- 6. Pick Up
- 7. Speech/Voice
- 8. Hang Up

### **WIRING DIAGRAM**

