

LEGEND 700 SERIES WIRELESS APPLE CARPLAY



Operations manual

TABLE OF CONTENTS

1. WIRELESS CARPLAY - CONNECTION PROCESS	. 3
(1) Connect Bluetooth	. 3
(2) Connect HU WiFi	
(3) Connect CarPlay	. 4
2. WIRELESS CARPLAY - DISCONNECTION PROCESS	
(1) Disconnect CarPlay	. 5
3. WIRELESS CARPLAY - ADD ADDITIONAL DEVICES	
(1) Disconnect CarPlay	
(2) Disconnect Bluetooth	. 5
4. WIRELESS CARPLAY - SWITCH DEVICES (SWITCH CP/AA/BT DEVICES)	
(1) Disconnect CarPlay	
(2) Select the device to connect from the device list	. 6
5. WIRELESS CARPLAY - DELETE DEVICES	. 7
6. WIRELESS CARPLAY - DEVICE CANNOT CONNECT.	. 7



LEGEND 700 SERIES WIRELESS APPLE CARPLAY

1. WIRELESS CARPLAY - CONNECTION PROCESS

(1) Connect Bluetooth

Click on the Apple Carplay icon on the main screen, and a dialog will appear. Turn on Bluetooth and WiFi on the phone you want to connect. Click the Bluetooth button to enter the device list pairing interface. There are two pairing methods:

- Enter the Bluetooth pairing interface on the phone, click the search button on the HU, find the phone name, and click pair.
- 2. Search for the HU from the phone's list and click pair.

Click the Apple Carplay icon on the main screen:





Turn on Bluetooth and WiFi on the phone:






HU Bluetooth search:



Phone Bluetooth pairing:



HU pairing successful:



Phone pairing successful:



(2) Connect HU WiFi

After the Bluetooth pairing is successful, The phone will automatically connect to Wireless CarPlay, due to differences between phones, it's best to open the WiFi interface on the phone to quickly connect to the HU WiFi, speeding up the Wireless CarPlay connection. (The phone will automatically request to enable Wi-Fi to connect to Wireless CarPlay once connected.)

Phone opens WiFi interface:



(3) Connect CarPlay

When pairing for the first time, the phone will prompt for CarPlay authorization. Choose to authorize the use.



If you select later, the CP will not be connected for the first time and Carplay will be turned off, you can open the Carplat button at the universal carplay, and the phone will automatically connect to the wireless CP after opening







Successfully connected to CarPlay:



2. WIRELESS CARPLAY - DISCONNECTION PROCESS

(1) Disconnect CarPlay


Click the Carplay exit icon, click the device icon on the top bar to enter the device list, click the CarPlay running icon, and disconnect the connected CarPlay device.

CarPlay interface click exit icon (JBL):






Click the device button on the top bar:



Click the CarPlay icon to disconnect the CarPlay device:




3. WIRELESS CARPLAY - ADD ADDITIONAL DEVICES

(1) Disconnect CarPlay

Click the Carplay exit icon on the HU, click the device icon on the top bar to enter the device list, click the CarPlay running icon, and disconnect the currently connected CarPlay device.






(2) Disconnect Bluetooth


Click the icon to return to the main screen, then click the Bluetooth icon on the main screen to enter the Bluetooth pairing interface. Click the Disconnect button for the connected device to disconnect the Bluetooth device. You can then add another device (Wireless CP/Wireless AA/ Bluetooth) following the respective procedures.

Click the Bluetooth icon:





Click the Disconnect button to disconnect the BT device:



Below is a demonstration of adding a device:

Phone opens BT interface, HU opens BT search interface:






Click pair:



Pairing successful:



4. WIRELESS CARPLAY - SWITCH DEVICES (SWITCH CP/AA/BT DEVICES)

(1) Disconnect CarPlay


Click the Carplay exit icon, click the device icon on the top bar to enter the device list, click the CarPlay running icon, and disconnect the connected CarPlay device.

(2) Select the device to connect from the device

- If it's a CP device, click the CarPlay running icon (if the device has been connected to CP before, if not follow the Wireless CarPlay - Add Additional Devices and Wireless CarPlay - Connection Process).
- If it's an AA device, click the AA running icon (if the device has been connected to AA before, if not follow the Wireless Android Auto - Add Additional Devices and Wireless Android Auto - Connection Process).
- If it's a BT device, click the Bluetooth phone button and the Bluetooth music button (if the device has been connected to BT before, if not follow the BT device pairing process).


Below is a demonstration of switching from a CP device to a BT device:

Click the CarPlay icon to disconnect the CarPlay device:






Click the BT device's Bluetooth phone button and Bluetooth music button:




5. WIRELESS CARPLAY - DELETE DEVICES


- (1. If the CarPlay device is connected: Disconnect Wireless CarPlay, click the delete button next to the device.
- (2. If the CarPlay device is not connected: Click the delete button next to the device.


Click the CarPlay icon to disconnect the CarPlay device:





Click OK to delete the device:





6. WIRELESS CARPLAY - DEVICE CANNOT CONNECT

(1. When connecting the CarPlay device via USB, choose to use CarPlay wirelessly.



(2. Check whether the Carplay is turned on, if not, please turn it on







(3. Tried the above methods but did not work, please clear the CarPlay devices from both the car's system and the head unit (HU), then try pairing again.

Click "Forget This Car":





